

Hybrid Golf Watch

voice caddie T2

User Manual



voice caddie

UcommTechnology Co., Ltd.

Golf Mode

► Distance to the Green

When entering the Golf Mode, your T2 will search for GPS. Once it acquires the satellite signals, it will automatically recognize the course and hole and display the distance to the green.



Hole 17 / Score +23 / 3rd shot
Back of the Green

Center of the Green

Front of the Green

One green



Hole 17 / Score +2 / 2nd shot

Yards

Two greens

* The score displayed is the score up to the previous hole.

► Shot Distance

To begin measuring your shot distance, press the **Shot** button at your starting point. The T2 will continuously display the distance from the starting point to your current location. To exit, press the **Menu** button.



One green



Two greens

Shot Distance : 249 Yards

Menu

Press the **Menu** button in Watch mode, and use the **Up/Down** buttons to navigate between menus. Press the **Select** button to move on to each menu and the **Menu** button to return to the previous screen.



► GOLF MODE

Distance to the green, Measuring shot distance, Manual hole selection, Fitness during round and Recording your score.



► SCORECARD

1. History : View your history. (date, course, and score)
2. Tempo : Measure your swing tempo.



► FITNESS MODE

1. Walk/Run : Track time, speed, distance, and calories burned for your walk or run.
2. Cycling : Track time, speed, distance, and calories burned for your ride.
3. Stopwatch : Measure elapsed time.



► SETTINGS

1. Date / Time
2. Unit / Sound
3. Auto-scoring(On / Off)
4. Alarm
5. About : View the software version, demonstration, data initialization, GPS Test.

Getting Started



* Power On / Off : Press and hold the **Power** button.

► Charging

Using the USB charger provided, align the charging clip with the contacts (4-pin) on the back of the T2 and attach the clip securely. Charging time is approximately 2 hours.



While charging

After fully charged

► Using VC Manager

1. Visit www.voicecaddie.com to download T2 VC manager.
2. Connect the device to a USB port on your computer using USB cradle.
3. You may update golf course or upload your round data to review each shot on an aerial map.

※ Please visit “Golf Course Update” page for more information to use VC manager.

Settings

► Date / Time

Settings



Date/Time



Date

or

Time

Use the **Up/Down** buttons to adjust the day, month, year, hour, and minute. Press the **Select** button to confirm each field. To return to the watch screen, press the **Menu** button.



► Format

Settings



Date/Time



Format

Set the time format to 12-or 24-hour.

► Unit / Sound

Settings



Unit/Sound



Golf

or

Fitness



Golf Mode

Select yards or meters.



Fitness Mode

Select kilometers and miles.

Settings

▷ Weight

Settings



Unit/Sound



Weight

To change between kilograms and pounds, press and hold the **Down** button. Use the **Up/Down** buttons to adjust weight.



▷ Sound

Settings



Unit/Sound



Sound

Turn system sounds On or Off.

▶ Auto - scoring

Settings



Auto - scoring

Turn 'Auto-scoring' On or Off.

▶ Alarm

Settings



Alarm

Use the **Up/Down** buttons to turn the alarm on or off, then press the **Select** button to confirm. If the alarm is on, use the **Up** and **Down** buttons to adjust the hour, minute, and AM/PM. Press the **Select** button to confirm each field.

Fitness Mode

► Stop Watch

Menu



Fitness



Stop Watch

To start, pause, and reset the stopwatch, press the **Select** button.



► Walk, Run & Cycling

Menu



Fitness



Walk, Run or Cycling

When entering Walk/Run and Cycling Mode, your T2 will search for GPS. Once it acquires satellite signals, it will automatically start tracking your walk /run/cycling. To reset data, press the **Down** button.
*To be more accurate, specify your weight in Settings.



To change between speed and pace mode, press and hold the **Up** button.

* To view the time and date, press and hold the **Menu** button.



Speed Mode



Pace Mode

Scorecard

► History

Menu

Scorecard

History

T2 displays the date, name of the golf course, and score of your most recent round.

To view the previous histories, press the **Down** button.



* History stores up to 200 rounds.

► History Modification

Select a course you need to modify, then press the **Up/Down** buttons to adjust your score.

Press the **Select** button to confirm.

To return to the Menu screen, press the **Menu** button.



► History Deletion

Select a course you need to delete, then press and hold the **Up** button.

► Swing Tempo

Menu

Scorecard

Tempo

T2 will automatically measure your swing tempo.



Backswing : 0.92 seconds
Downswing : 0.33 seconds
Swing Tempo : 2.77 (backswing to downswing ratio)

Golf Mode

► Scorecard

T2 will automatically display scorecard if the 'Auto-scoring' function is selected in Settings. After each hole, you may check and modify the score.



*Press and hold the **Up** button to manually display the scorecard. To return to the previous screen, press and hold the **Select** button.

► Exit Golf Mode

When exiting Golf Mode by pressing the **Menu** button, the score is displayed and, when the button is pressed, the screen returns to the Menu after checking the calories burned during round.



Golf Mode

► Manual Hole Selection

To manually select a hole, press the **Up/Down** buttons simultaneously.



* Hole selection: Manually adjust a hole using the **Up/Down** buttons and press the **Select** button to confirm.

► Time in the Golf Mode

Press and hold the **Menu** button.
The present time is displayed while the button is held.

► Light in the Golf Mode

Press and hold the **Shot** button.

► Fitness in the Golf Mode

Press and hold the **Select** button.
The data is displayed while the button is held.



Time Played : 3 hours 35 minutes
Walked Distance : 2.87 miles
Calories burned : 897 calories