

Fitness Mode

Walk / Run

Fitness Menu > Walk / Run

When entering Walk / Run Mode, your T1 will search for GPS. Once it acquires satellite signals, it will automatically start tracking your walk / run. To reset data for your current walk or run, press the **DOWN** button.

*For more accurate information, enter your weight in Settings.



Duration: 6 hours 25 minutes
Speed: 15.8 mph
Distance: 97.8 miles
Calories Burned: 3400 Calories

Cycle

Fitness Menu > Cycle

When entering Cycle Mode, your T1 will search for GPS. Once it acquires satellite signals, it will automatically start tracking your ride. To reset data for your current ride, press the **DOWN** button.

*Display as above.

Stopwatch

Fitness Menu > Stopwatch



To start, pause, and reset the stopwatch, press the **SELECT** button.

Settings



Time / Date

Settings > Set > Time / Date



Automatic
Set the time and date automatically. Use the **UP** and **DOWN** buttons to select your time zone. Press the **SELECT** button to confirm.
*Requires GPS signal.



Manual
Set the time and date manually. Use the **UP** and **DOWN** buttons to adjust the day, month, year, hour, and minute. Press the **SELECT** button to confirm each field.



Format
Select 24-hour or 12-hour notation.

Settings

Units

Settings > Set > Units



Golf
Select yards or meters.

Fitness
Select miles or kilometers.

Weight
Select pounds or kilograms.

Sound

Settings > Set > Sound

Turn system sounds on or off.

Weight

Settings > Set > Weight

Use the **UP** and **DOWN** buttons to adjust your weight, then press the **SELECT** button to confirm.

Golf Demo

Settings > Set > Golf Demo

View a demo of the golf features without a course or GPS signal.

Factory Reset

Settings > Set > Reset

Reset all settings and history to the factory default.

Settings

Alarm

Settings > Alarm



Use the **UP** and **DOWN** buttons to turn the alarm on or off, then press the **SELECT** button to confirm.



If the alarm is on, use the **UP** and **DOWN** buttons to adjust the hour, minute, and AM/PM. Press the **SELECT** button to confirm each field.

About

Settings > About

View the software version on your T1.

Reboot

*Should your T1 freeze or become otherwise unresponsive, press and hold the **LIGHT**, **MENU**, **UP**, and **DOWN** buttons for 1 second simultaneously. Your T1 will reboot automatically. Your settings and history will still be saved.



Notes

Terms and Conditions:

Voice Caddie warrants its product against defects in materials and workmanship for a period of one year from the date of original retail purchase. If a defect exists, at its discretion Voice Caddie will: (1) repair the product at no charge; (2) exchange the product with a product that is functionally equivalent to the original product. Voice Caddie shall have no obligation to repair, or replace until the product is received and evaluated by Voice Caddie. This warranty does not apply: (1) to damage caused by accident, abuse, misuse, misapplication, or damage caused by non-Voice Caddie product or peripherals; (2) to damage caused by service performed by anyone who is not a Voice Caddie Authorized Service Provider; or (3) to a product or part that has been modified without the written permission of Voice Caddie.

Warranty Procedures:

Email us at rma@voicercaddie.com to receive a return merchandise authorization (RMA) number prior to returning any merchandise. A copy of the original purchase receipt is required to verify the date of purchase. If a return is approved, please send the unit along with a copy of the original purchase receipt and the RMA number marked clearly on the outside of the package. Shipping fees accrued for returns are responsibility of the sender.



voice caddie
Tel: 888-939-3978
E-mail: contact@voicercaddie.com
www.voicercaddie.com

Hybrid Golf Watch

voice caddie T1 User Manual



voice caddie
UComm Technology, Inc.

Getting Started

The home screen shows the time, date, and day of the week. To turn on the LED light, press and hold the **LIGHT** button. To check remaining battery, press and hold the **SELECT** button.



Charging

Using the USB charger provided, align the charging clip with the contacts (4-pin) on the back of the T1 and attach the clip securely. Plug the charger into a USB port on your computer or into any USB power adapter.
Charge time is approximately 2 hours.



VC Manager

The T1 comes preloaded and ready to use with approximately 30,000 courses worldwide. Use the VC Manager to upload newly added courses and/or update software. Instructions for downloading the VC Manager are available on the Voice Caddie website (www.voicercaddie.com). A complete list of courses is available on our website.

Menu

Use the **UP** and **DOWN** buttons to navigate between menus. Press the **SELECT** button to confirm. Press the **BACK** button to return to the previous screen.



Golf Menu

- ▶ **Play Golf:** View the distance to the green, measure your shot distance, and record your score.
- ▶ **Tempo:** Measure your swing tempo.
- ▶ **History:** View your rounding history (date, course, and score).



Fitness Menu

- ▶ **Walk / Run:** Track time, speed, distance, and calories burned for your walk or run.
- ▶ **Cycle:** Track time, speed, distance, and calories burned for your ride.
- ▶ **Stopwatch:** Measure elapsed time.



Settings

- ▶ **Set:** Change preferences, set your weight, view the golf demo, and reset settings.
- ▶ **Alarm:** Set an alarm.
- ▶ **About:** View the software version.

Golf Mode

Distance to the Green

Golf Menu > Play Golf

When entering Play Golf Mode, your T1 will search for GPS. Once it acquires satellite signals, it will automatically recognize the course and hole and display the distance to the green.



One Green
Distance to the front, center, and back of the green.



Two Greens
Distance to the front, center, and back of both left and right greens.
*Applies only to courses with two greens.

Shot Distance

Golf Menu > Play Golf > SHOT

To begin measuring your shot (or walked) distance in Play Golf Mode, press the **SHOT** button at your starting point. The T1 will continuously display the distance from the starting point to your current location.

To exit shot distance, press the **BACK** button.



One Green
Shot Distance: 128 yards
Front of the Green: 346 yards
Center of the Green: 358 yards
Back of the Green: 371 yards



Two Greens
Shot Distance: 128 yards
Front of the Left Green: 335 yards
Center of the Left Green: 346 yards

Golf Mode

Manual Hole Selection

Golf Menu > Play Golf > HOLE



To manually select a hole in Play Golf Mode, press the **HOLE** button, then press the **UP** and **DOWN** buttons to adjust the hole number. Press the **SELECT** button to confirm.

Scorecard

Golf Menu > Play Golf > SCORE



To record your score in Play Golf Mode, press the **SCORE** button, then press the **UP** and **DOWN** buttons to adjust the score. Press the **SELECT** button to confirm.

Swing Tempo

Golf Menu > Play Golf > TEMPO

To view your swing tempo in Play Golf Mode, press the **TEMPO** button before your shot. Your T1 will automatically measure and display your swing tempo.

*For an accurate reading, hold your address for 1 second before you swing.
*Backswing: time from address to the top of the swing
*Downswing: time from the top of the swing to impact



Back swing: 0.92 seconds
Downswing: 0.33 seconds
Swing Tempo: 2.77
(backswing to downswing ratio)

Golf Mode

Time and Date

Golf Menu > Play Golf > MENU



To view the time and date in Play Golf Mode, press and hold the **MENU** button.

Fitness in Golf

Golf Menu > Play Golf > UP



Walked Distance: 4.6 miles
Time Played: 4 hours 25 minutes
Calories Burned: 887 calories

Golf Mode

Swing Tempo

Golf Menu > Tempo

In Swing Tempo Mode, your T1 will automatically measure and display your swing tempo for each of your practice swings.
*For an accurate reading, hold your address for 1 second before you swing.



Back swing: 0.92 seconds
Downswing: 0.33 seconds
Swing Tempo: 2.77
(back to downswing ratio)

History

Golf Menu > History



In History, your T1 will automatically display the date, course, and score for your most recent rounding. To view older roundings, press the **DOWN** button. To view more recent roundings, press the **UP** button.
*History stores up to 200 roundings.

Remaining Battery

Golf Menu > Play Golf > SELECT/HOLE



To check the remaining battery in Play Golf Mode, press and hold the **SELECT** button.