

# SL3

## User Manual

Detailed description of this product is  
available on the website of Voice Caddie.

[www.voicecaddie.com](http://www.voicecaddie.com)



**VOICE CADDIE**

## What's In the Package

Body, Pouch, USB Cable, User Manual, Cleaner

## Product Parts



① Laser Receiver / Object Lens

② Laser Diode

③ OLED Brightness Adjustment Button

④ Power / Measure Button

⑤ Slope OFF (Tournament Mode) Display Light

⑥ USB Recharging Port

⑦ Eyepiece and Focus Control Unit

⑧ Touch LCD Screen


⑨ GPS Receiver

## Turning on the Power

Press Power/Measurement Button to activate the laser function and turn on Touch LCD Screen.

※ GPS will be activated only at entering Golf Mode.

OLED Screen



Touch LCD Screen



After the power is ON

## Recharging


### Battery

- Recharge the battery when (🔋) icon is displayed on OLED screen.
- When the icon is blinking, entering the golf mode from the LCD touch screen is disabled and the power can go out. Only the laser functions are available.  
(Good for 36 holes)

### How to recharge


- It is recommended to use the exclusive USB cable provided.  
C-type USB must be used.

# Explanation of OLED Screen



# Discription of the LCD Touch Screen

## LCD Touch Screen



## Exit the LCD touch screen

- Exit the touch screen by sliding down the screen from the Menu screen
- After the turning the screen off, you can turn it back on by touching the screen for 3 seconds.



## Focus Adjustment

Adjust the focus by turning the diopter adjustment on the eyepiece to enhance the image on the OLED screen.

# Unit Change

Unit change is only available on the LCD touch screen.

## How to change the unit (of measure)


- Changing the unit on the Menu Screen.
- Touch the (⚙️) on Menu Screen > Golf Option > Unit Change.



- Changing the unit during the Golf Mode
- During the Golf Mode, Swipe up the screen to enter the Golf Option.
- Golf Option > Touch the 'Unit Change'



## OLED viewfinder when changing unit




# OLED viewfinder Brightness Adjustment

Changing the brightness of the OLED by adjustment button only.


## OLED viewfinder Brightness

· 6 levels

## OLED viewfinder Brightness Adjustment Method

- Pressing the brightness adjustment button (  ) shortly, the brightness level will be adjusted.

## OLED viewfinder when Adjustment Brightness



## Slope Function ON/OFF

Turning on/off the Slope Function is only available on the LCD touch screen.

### Turning on/off the Slope Function from the menu screen


- Slope ON/OFF on Menu Screen
- Touch the (⚙️) > Golf Option > Slope > ON



- Slope ON/OFF during the Golf Mode
- Swipe up the screen to enter the Golf Option during the Golf Mode.
- Golf Option > Slope > ON




### OLED viewfinder when the Slope Function ON/OFF







# Distance Measurement


## Spot Measurement

- Press Power/Measurement Button (  ) briefly to measure.
- Quickly measure various targets such as fairways, bunkers, and hazards to show the distance.



## Pin Tracer™ Measurement


- After power on, press and hold the Power/Measurement button (  ) and scan around the pin (up to 3 seconds)
- When scanning the surroundings of the pin, it will recognize the closest object as a pin and give you a jolt (visual ring & vibration).



# How to use Touch LCD


## Entering the Golf Mode

- Touching the Golf Mode Icon to recognize holes automatically after GPS reception. (Please activate GPS in the space without obstacles of roof and tree.)



## End of the Golf Mode


- Slide the screen down from above during the Golf Mode to end the mode.





# How to use Touch LCD

## Screen at entering the Golf Mode

- The course view screen will be displayed when initially entering the Golf Mode
- Touch the slide left and right to change the Guide Screen.



※ Images of Course View, Green View and Putt View could differ by the situation of the area and the corresponding golf course.

※ When linked with the App, the  icon is displayed, and when not linked, the  icon is displayed.


# How to use Touch LCD

## Course Preview

- Touch the (🔄) icon in Tee Box to replay the Course Preview.

Return to the Golf Mode after the end of replay.

\*Touch the screen during the replay to return to the Golf Mode immediately.



## Bunker / Hazard Guide

- Touch a bunker or a hazard to guide the distance to the front and back of the bunker or the hazard.
- More convenient to touch on enlarged screen




# How to use Touch LCD

## Green Undulation

- Divide the contour of the green to 11 stages to provide more precise green undulation.

## Green Zoom (2 stages)

- Touching the (⊕) icon to enlarge the green. (Support the pin reload function)
- Touching the icon one time (1st stage) / 2 times (2nd stage)



## Active Green View


- The shape of green rotates automatically by the position of a golfer.





# How to use Touch LCD

## Putt View


- Guide high and low, distance to a pin from a ball.




- ① The distance from the ball to the pin
- ② The elevation from the ball to the pin
- ③ If you move to the ball position and click the ball icon(  ), it'll move the ball to the current location.
- ④ If you move to the pin position and click the pin icon(  ), it'll move the pin to the current location.

# How to use Touch LCD

## GPS Pin Assist

- GPS coordinates are used to block the area behind the green so that objects (such as trees) measured against the background of the green is not recognized as pins.
- How to use  
Available only when entering Golf Mode (GPS enabled),  
GPS pin assist function must be set to ON.
- The Combination of GPS Pin Assist and Pin tracer™ measurements enables more accurate measurements.
- When the GPS Pin Assist is on, GPS Pin Assist icon(  ) will be displayed while measuring with the Pin Tracer



# How to use Touch LCD

## How to ON/OFF the GPS Pin Assist

- When turning on/off GPS Pin Assist from the Menu screen
  - Touch the (⚙️) icon on Menu Screen> Golf Option > GPS Pin Assist



- When turning on/off GPS Pin Assist in the Golf Mode
  - Enter the Golf Settings mode by swiping up in the Golf Mode
  - Golf Option > GPS Pin Assist






# How to use Touch LCD

## Manual measurement of driving distance

- After entering the Golf Mode, touching the (🕒) icon in Course View/Green View/Yardage View to provide the driving distance of a previous shot.

## How to measure the driving distance manually

- Touch the (🕒) icon before the shot. Display the driving distance in the icon at moving to a spot where the shot drops.
- Touching the (🕒) icon again to reset the measurement of driving distance.



# Precautions for Using the Product

---

## Precautions for Using the Product

1. This device may be affected by the weather such as rain and clouds, and the surrounding environment.
2. Depending on your environment and how you use it, battery consumption may increase.
3. Do not use this device for any other purpose such as children's toys.
4. If the person's eye is exposed directly to laser irradiation, or exposed to the sun or strong light through this device, his/her eyesight may be impaired.
5. The lens is coated, so care must be taken when cleaning. In order to prevent damage to the lens, do not touch the lens directly with fingers and rough material.
6. Do not keep this device in hot places such as exposed to direct sunlight, in closed vehicles on hot days, or with heaters.
7. Regularly recharge the device so that the battery is not fully depleted. Fully depleting the battery may shorten the battery lifetime.
8. Do not randomly modify this device such as dropping, throwing, putting in foreign substances, disassembling, incineration, etc.
9. Please use only a dedicated battery.
10. Be careful not to open the pouch and drop the product due to strong movement.
11. Natural cosmetic deformation and degradation of performance due to normal use and aging are not warranted.

## Safety Precautions for Using the Laser

1. The laser emitted from this product is invisible. It is safe to operate by your intention according to the contents of this manual.
2. Warning : It is dangerous to look at the laser with other optical instrument, please do not look at the laser through the telescope. If you handle the product arbitrarily without following this manual, you may be injured by the laser.
3. Information about laser
  - Wavelength : 905nm, Pulse Width: 20nsec, Energy : 0.270μJ or less, Divergence Angle : 2mrad
4. Class 1M laser product in accordance with IEC 60825-1:2014

## Caution

---

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

## Caution

---

1. Reorient or relocate the receiving antenna.
  2. Increase the separation between the equipment and receiver.
  3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  4. Consult the dealer or an experienced radio / TV technician for help.
  5. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
    - 1) This device may not cause harmful interference, and
    - 2) This device must accept any interference received, including interference that may cause undesired operation.
  6. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
  7. The device can be used in portable exposure condition with out restriction.
- \* Risk of explosion if battery is replaced by an incorrect type.  
Dispose of used batteries according to the instructions.

## Trademark Registration

---

1. Bluetooth is the trademark of Bluetooth SIG, Inc.
2. Other trademarks and copyrights are the assets of corresponding business company.

## Warranty as follows

---

1. This device was produced through strict quality control and thorough inspection, and may be exchanged or reimbursed in accordance with the Fair Trade Commission Notice Consumer Dispute Resolution Criteria.
2. If any change problem to defect occurs in normal use, the product will be repaired free of charge within the warranty period returns for inaccuracies will be at customers.
3. In case of product abnormality caused by user's carelessness even if it is within the free warranty period, or in case that the warranty period has expired, it can be repaired on a charge.
4. For after-sales service and damage compensation, please present this warranty and proof of purchase (receipt).

## Warranty Conditions

---

Product Name	VOICE CADDIE SL3
Serial No.	
Purchase Date	
Dealer	
Dealer Contact	
Buyer's Name and Contact	
Name / Phone	
Free Warranty Period	For one year after the purchase of the product (6months for components)
Exchange and Refund Period	Change to 30 days return

# Specifications and After-Sales Service

Product	VOICE CADDIE SL3
Key Features	6X Magnification, 2 Color OLED, Pin Tracer, V-Algorithm, Slope & Non-Slope, Course Preview, Green Undulation, Putt View
Size/Weight	41.1mm(width) X 77.7mm(Height) X 109mm(Length) / 220g
Measuring Range	5 to 1,000 yards (1 yard = 0.91m)
Margin of Error	Laser : $\pm 1$ yard / GPS: $\pm 3$ yard
Power / Battery	Higher than 5V/1A, 3.7V Lithium-polymer 1,000mAh
USB / Bluetooth	USB 2.0 / BT 5.0
Recharging Hours	About 90 minutes
Hours of Use	About 45 hours (Hours of use can be changed by the use method and surrounding environment.)
Manufactured by/in	VC Co., Ltd / China
Imported/Sold by	VC Co., Ltd
Company	VC Co., Ltd



Call : 562-926-3978  
 6940 Aragon Cir. Unit 6  
 Buena Park, CA 90620



OFFICIAL RANGEFINDER OF THE LPGA

[www.voicecaddie.com](http://www.voicecaddie.com)